

Operation of the Cobra Autosampler on the 8610V gas chromatograph

Insert the 10ul syringe in the syringe holder. The syringe is SRI part#8640-0003.

Wiggle the needle into the holes in the center and lower needle supports. The holes are small so you have to move the needle around until you feel the needle fall into the hole of the lower support.

Use a finger to lift the lower needle support so the needle can not escape while performing the rest of the syringe installation.

