

Operation of the Cobra Autosampler on the 8610V gas chromatograph

Loosen the thumbscrew of the plunger retainer. Lift the thumbscrew slightly and wiggle the head of the syringe plunger into the slot. Then tighten the thumbscrew. This is slightly awkward and it may help to have a second person the first time you do this.

Position the syringe flange in the slot. Rotate the syringe so the graduations along the glass barrel are visible.

Rotate the clamp to secure the syringe in place.

