



Air Monitoring

- Vacuum Gauge, *page 374*
- Sample Inlets, *page 377*
- Quick-Connect Stem Protector, *page 378*
- Miniature Air Sampling Kits, *page 379*
- Vacuum Bag Sampler, *page 379*
- Small Cylinder Stand, *page 386*
- TPED Compliant Sample Cylinders, *page 390*



Analytical Reference Materials

- Method 525.2 Herbicide Analytes, *page 414*
- Method 525.2 Herbicide Mix, *page 414*
- Method 535 Internal Standard, *page 417*
- Method 535 Surrogate Standard, *page 417*
- Method 535 Individual Compounds, *page 417*
- EPA 8061A Phthalate Esters Mixture, *page 428*
- EPA 8061A Hexyl 2-Ethylhexyl Phthalate Standard, *page 428*
- EPA 8061A Phthalate Esters Kit, *page 428*
- Pesticide Surrogate Mix, EPA 8080, 8081, *page 429*
- Oxy Set-Up Blend, ASTM D6730-01, *page 471*
- 0.16µg/dL Forensic Ethanol Solution, *page 477*
- Forensic Drug Screen Test Mixture, *page 478*
- Forensic Drug Screen Internal Standard, *page 478*



Applications

Too many to list! Look for the **NEW!** symbol in the HPLC and GC Applications sections beginning on page 488.

