

CONTENTS

DETAILED DIAGRAM OF THE ECONOLINE® COLUMN	Page 04
1. INSERTION/REMOVAL OF THE QUICK-LOCK BAYONET SYSTEM	Page 05
2. FRIT REPLACEMENT	Page 05
3. INSTALLATION OF Essential Life Solutions MPLC FITTINGS	Page 06
4. ELIMINATION OF DEAD VOLUME	Page 06
5. OPERATION OF THE COLUMN	Page 07
6. SOLVENT RESISTANCE	Page 08
7. PACKING INSTRUCTIONS	Page 09
8. CLEANING METHODS FOR PACKED COLUMNS	Page 12
9. TROUBLESHOOTING	Page 14

The general conditions and the Essential Life Solutions Ltd warranty conditions apply in the version that is valid in each case. All information contained within this manual is without obligation, as it is subject to technical changes resulting in product improvement.

Revision 2.0
1/1/02