



¹⁾ CAUTION: Open connection tubing first to prevent cracking of the packing due to vacuum originated by removal of the piston.